


----- AUTO GUIDE (CONTROL BOX) CONNECTOR -----

- EM-10[A,B]
- EM-200[A,B]
- EM-500[, ,]
- PD-6XY
- EMD



HIROSE HR12-10R-8SD
FEMALE
(TOP VIEW)

No.	
1	DEC
2	DEC
3	H.SPEED
4	NC
5	+12V
6	RA(-)
7	RA(+)
8	GND